


Eberspaecher Bunk Heater

EasyStart Pro OEM – Quick Ref. Guide



Part number: 22.1000.35.4300

1. DISPLAY
2. BUTTON AND ROTATING DIAL
3. LED INDICATOR RING
4. BACK BUTTON



Key Features

- Fulfills NA OEM requirements with same mounting as Digimax.
- 10 hours (600 minutes) run time.
- Interlock logic (park brake / ignition switch).
- Low voltage disconnect: 11.4 V (for 12 V systems).

Menu Navigation and Selection

- If the display is off, pressing any key will wake up the display.
- Rotate dial to navigate the main menu or sub-menus as well as change values and selections.
- Press dial to confirm value/selection.
- Long press dial (> 2 seconds) to immediately start or stop heater.
- Press back button to return to previous menu/selection.

Heating Mode – 10 hours run time

1. Select  symbol (Heating Mode).
2. Rotate dial to set desired temperature. Press dial to accept.
3. To adjust the desired temperature, select  then select .
4. To turn off heater, select  then select **OFF**.


Please note: The heater may take up to 6 minutes to produce heat.

Please note: To allow heating mode, park brake / ignition switch condition must be met; If not “Check Interlock” message appears.

LED Indicator Ring

- Off: Heater off.
- Red ring: Heating mode.
- Red flashing ring: Fault in heater or controller.

Eberspaecher Bunk Heater EasyStart Pro OEM – Quick Ref. Guide



Settings Menu

The following options are available in the settings menu ()

 Change temperature unit (°C or °F).

 User level fault diagnostics.

 User level reset (not a factory reset).

Diagnostics Read Outs

If a fault occurs: LED ring flashes red and error message is shown.

1. Take note of fault message and press the dial to acknowledge.
2. Consult manual for information or contact technical support.
3. Visit an authorized Eberspaecher dealership if problem persists.

Maintenance Interval – preventative maintenance

If the maintenance interval option is enabled, after a specific number of heater hours of use you will see a “Service” message reminder to do preventative maintenance on an authorized dealer.

Maintenance Recommendations

- Run heater on a high temp. setpoint for 15 minutes every month.
- If you observe increased heater exhaust smoke, contact your maintenance department or the Eberspaecher technical support.
- Check often heater ducting and piping for restrictions or damage.

*Refer to the controller manual for detailed information, available at the Partner Portal
(<https://partner.eberspaecher.com/en>)*

*If you have technical questions, please contact the Technical Support Team:
help@eberspaecher.com / +1 800 387 4800.*

Eberspaecher Climate Control Systems
+1 800 387 4800 www.eberspaecher-climate.com